



iNavX

#1 Marine Navigation App

Understanding the Basics



iNavX



Table of Contents

Main Screen	Page 3
iNavX Account	Page 5
Opening and Selecting Charts	Page 7
iNavX In-App Chart Store	Page 9
Using Charts	Page 10
Instruments	Page 18
TCP/IP NMEA Client	Page 20
Waypoints	Page 22
Routes	Page 26
Tracking	Page 29
Anchor Alarm	Page 30
Forecasts: Tide / Weather / GRIB	Page 31
Quick FAQs	Page 34
Connecting iNavX to 3rd Party Systems	Page 38




Start-Up or Main Screen

When you open iNavX, the app defaults to the **Chart View** screen, this is your main screen. (depending on your user state, the Chart View will either show the last opened Chart of the World Chart – as shown)

From here you can navigate to all the different areas in the app, through the menu bar at the bottom or settings at top right.



Let's start by clicking the “**Charts**” link at the top left. This will take us to our Charts list where we can access and purchase Charts




Charts Page

My Charts shows a list of all charts that are available to be used


These include the pre-installed NOAA Charts that are made available for free to all users ...

And, purchased charts tied to your iNavX Account








Store shows a list of all Charts that are available for Purchase

To complete a purchase, select the Chart and click **Buy**




Logging into iNavX Account

To complete a Chart purchase and to see all Charts, a user must be logged into their iNavX Account

-  Open the **More** menu
-  Select **Account**
-  Sign in **Email** and **Password**
-  **Sign up** to create a new account, or request a new password
-  Once complete, Account will show the user as **Logged In**

Let's click "**Chart**", at the bottom to continue



Opening a Chart

A step by step guide to download and access specific charts



1/ Open the **My Charts** list



2 & 3/ Select specific Chart Group or Region, you may be prompted to **Download Chart List** to display available Charts



4 & 5/ Select the specific Chart and confirm if you want to download that Chart on the entire Group / Region










6/ Downloading Charts requires an internet connection (either WiFi or cell coverage)



7/ Charts that are local, already downloaded from the chart server will be shown in **Bold**. These charts are available to be used Offline






8/ Select the desired Chart to open



Selecting Charts


The Chart List can be filtered using the three action buttons at the top

-  **Magnifying Glass:** Opens the Search bar, to search chart list by chart number or name
-  **Triangle:** Sorts Charts by proximity, charts closest to the current location are shown first
-  **Clock:** Sort Charts by history, shows Charts recently opened

Charts that are local (previously downloaded to the device) will be shown in **Bold**. When a Chart is selected that is not local, it must be downloaded from the Chart server before using, this requires an internet connection







To **Delete** a downloaded Chart, simply **SWIPE** Left


Tip ... when returning to the chart list, Tap the magnifying glass to restore the full list. Previous filters and searches may truncate the results



iNavX In-App Chart Store

Directly through the app,
access the broadest set of
marine charts from all
your favorite providers.
Available today:

-  **Blue Latitude**
-  **Explorer**
-  **NV Charts**
-  **Navionics**
-  **Waterway Guides**
-  **... and more coming soon**



Step 1:

Select **Charts** from
Navigation Screen

Step 2:


Select **Store**

Step 3:

Choose your **Chart** from the
Store List









Step 4:


Click **Buy** to confirm Purchase



Understanding the Charts View Screen









Across the Top and Bottom of the App, you will find a number of options


-  **Charts** – this will take you to the My Charts and Chart Store page
-  **Chart Name** – The displayed Chart's name will be shown across the top.
-  **Settings** – depicted by the Gear Icon, is where all the Chart settings can be configured.
-  **Chart** – to display the Chart View.
-  **Waypoints** – save, import and configure Waypoints and Routes
-  **Track** – Manage Tracking settings
-  **Instruments** – See and configure all Instrument data
-  **More** – Menu for Account, Forecasts, Tools and Help sections



Using Charts

Once a Chart is selected from the Chart List, it will be displayed in the Chart View


-  **Zooming** – Pinch and Pull to zoom in and out on the Chart. The corresponding Scale will be shown at the lower left corner
-  **Scrolling** – Drag the chart in any direction to scroll
-  **“+” and “-”** – Use the + and – buttons to display a menu of the next Chart in the series, or a larger (more detail) or smaller (less detail) Chart. Note: not all Charts have the ability to change scale
-  **Full Screen** – The expand/contract button on the right side of the Chart View will toggle to Full Screen
-  **Compass and Instruments** – are shown at the top of the Chart, these can be added and removed from the screen with the Arrow button. Instruments can be configured with the ⓘ button
-  **North** – The directional arrow at the lower left corner is orientated to North on the Chart. The arrow will have a green border if the chart be be orientated to a Course-Up rotation or a North-Up orientation. Tapping the directional arrow will toggle chart rotation. When the Chart is rotated, the directional arrow will have a blue border
-  **Chart Information** – ⓘ to learn more about or remove, update, email, print or tweet the displayed Chart
-  **Tip ...** when viewing charts far away from current Lat/Lon, turn off Position Loc in Chart Settings



Measure Mode

Double-tapping on the Chart will start measure mode

This is shown by the **Green Dot** in the center of the Chart



Drag to measure distance and bearing between start point (**Green Dot**) and end point (Red Dot), results shown across the top of the Chart

To measure from the current position, single tap the Green Dot






Single tap Red Dot to create a Waypoint


Single Tap anywhere else on the chart to exit measuring



Location Details


Single tapping a location on the Chart will pull up Location specific details

-  **Location** – latitude, longitude, range and bearing
-  **Waypoint** – mark location as a waypoint
-  **Zoom** – another way to zoom in on current chart
-  **More Detail** – additional chart specific information as published by the Chart provider
 -  Raster Charts (ex. NOAA charts) have no additional chart details about nautical objects




Using Settings

Settings	When Enables		
Pos. Icon Loc.	Selection	Result	Automatically Display Best Detail Chart
	Ctr	Chart view is automatically scrolls such that the position icon is kept in the center of the Chart View. Note: this selection is automatically made when course up chart orientation is in use.	X
	Offset	Chart view is automatically scrolled such that the position icon is kept in the Chart view offset relative to course. Note: SOF must be at least 0.5 knots before an offset occurs.	X
	None	Chart view is not automatically scrolled	
Pos. Icon Color	Position icon will be filled with selected color. The color of the dot in the position icon indicated the accuracy of the plotted position: Gray = none, Yellow – weak, Green = strong, White = TCP/IP. Select clear color to enable plotting of “own” AIS target		
Pos. Icon Size	Position icon scaled between 75% and 150%		
Velocity Vector	A line form the position to the projected position in the selected minute(s) will be displayed. The projection I smade based on current speed and course. If the distance is set to “Max”, then the vector will always be 300NM in length regardless of speed. Note: AIS targets will cap vector length at 30 minutes.		
Velocity Vector	Velocity Vector will be drawn with selected color.		
Range Ring	A circle will be plotted with the selected radius around the position icon		
Waypoint for Course up Orientation	Course up orientation will use the active waypoint		
Night View	Night time friendly palette colors is used for the display of the chart		
High Resolution	Display raster charts at highest resolution. Note: This may cause chart loading and display performance to suffer		




Using Settings

Settings	When Enables	
Long Tap New Waypoint	Holding down on the Chart view for two seconds will create a new waypoint	
Waypoint Activated Alert	Will display an alert and sound when ever a waypoint is activated (i.e. Go To)	
Show Waypoints As	Waypoints are plotted on the Chart View	
	Selection	Result
	Title	Waypoints shown as title
	Icon	Waypoints shown as selected icon
	Both	Waypoints shown as title and icon
Show Waypoints	Waypoints are plotted on the Chart View	
	Selection	Result
	All	All Waypoints are plotted
	Route	Waypoints contained in the selected Route are plotted
	None	No Waypoints are plotted




Using Settings

Settings	When Enables	
Show Route	Routes are plotted on the Chart View	
	Selection	Result
	All	All Routes are plotted
	Selected	Selected Route is plotted
	None	No Route is plotted
Show Track	Track log is plotted on the Chart View	
Track Color	Track will be drawn in the selected color	
Show AIS	AIS Targets are plotted on the Chart view. Single Tap target in Chart view to show information view. AIS Target dot color coding: Yellow = no static data received, Green = static data received, Gray = no data received in last 5 minutes. AIS Target fill color coding: Dark Red = tracked, Orange = Class A, Magenta = Class, Red = SART.	
	Selection	Result
	All	All AIS targets plotted
	Underway	AIS targets with a SOG > 0.3 knots plotted
	Class A	Class A targets plotted
	Class B	Class B targets plotted
Show AIS Names	Display the AIS Target vessel name	
Show Wind Vector	Displays a line for the position at the True or Apparent wind angle	
Show Boundaries	Display the bounds of the available charts, this also enables chart selection in the Chart menu accessed by single tapping the chart	
Points of Interest	Displays Points of Interest, if subscribed to Waterway Guide data overlays. Select the guide region matching the chart region currently of interest.	



Using Settings










Settings	When Enables
Show NavAids	Display NavAids
Show Light Sectors	Displays light sections
Show Lat/Lon Grid	Display Latitude and Longitude grid lines
Show Soundings	Show depth soundings
Show Surface	Show surface annotations
Show Recommended Routes	Displays the recommended routes
Large NavAids	Show text and NavAids slightly larger with loss of some detail
Safety Depth	The depth at which to show the contour shading
US Symbols	Show US symbols, otherwise International




Instruments View

The Instruments view displays the data (see Datum Table below) from either the Location Services (GPS, WiFi, cell coverage) OR NMEA Data (received through a TCP/IP NMEA Client)

Selecting any row in the Instruments View will display the selected data by itself in a large font or in some cases as an analog graphic

-  **Units** – determine the format of the data
-  **Settings** – “gear icon” to filter what data is displayed
-  **True Bearings** – are disabled in Settings, magnetic bearings will be computed based on the position
-  **Compass Deviation** – can be used to calibrate the magnetic compass of the device
-  **The Compass Banner** – HDG position icon orientation and course up chart will use the device compass if available AND HDG is “**on**” in Settings” AND Location Services are used, otherwise COG will be used
 -  The compass measures heading relative to the top of the device
 -  The compass banner will have a yellow background if error is greater than 30 degrees
-  **Location Services** – To use Location Services, enter your devices Settings app, select “**Settings**”, “**Privacy**”, “**Location Services**” and turn “**ON**” for iNavX
 -  Note: Airplane Mode does disable the GPS receiver and WiFi reception



Configuring Instruments

Datum	Description	Location Services	NMEA 0183	NMEA 2000	Analog Graphic or Extended Data Available when "Show Digital is Disabled"
AAD	Anchor Alarm Drift	X	X	X	
ALT	Altimeter	X	X	X	
AWP	All Waypoints	X	X	X	X
ALV	Alternator Volts			X	
AWA	Apparent Wind Angle		X	X	X
AWS	Apparent Wind Speed		X	X	X
BAT	Battery Wind Vane		X		
BPR	Barometric Pressure	X			X
BSP	Boat Speed		X	X	X
BTW	Battery Volts			X	
BTW	Bearing To Waypoint	X	X	X	
COG	Course Over Ground	X	X	X	X
CON	Connection	X	X	X	
DBT	Depth Below Transducer		X	X	X
DPT	Depth		X		X
DTR	Distance Remaining In Route	X	X	X	X
DTW	Distance To Waypoint	X	X	X	
ETA	Estimated Time Of Arrival	X	X	X	
ETP	Engine Temperature			X	
FIX	Position Type		X	X	
FLC	Fluid Capacity			X	
FLL	Fluid Level			X	
FLR	Fuel Rate			X	
GSV	Satellites In View		X	X	X
HDG	Heading	X	X		X
HDM	Heading Magnetic		X	X	
HDT	Heading True		X	X	X
HPE	Horizontal Position Error	X	X	X	

Datum	Description	Location Services	NMEA 0183	NMEA 2000	Analog Graphic or Extended Data Available when "Show Digital is Disabled"
LAT	Latitude	X	X	X	
LON	Longitude	X	X	X	
MWD	Magnetic Wind Direction		X		
OIL	Oil Temperature and Pressure			X	
ROT	Rate Of Turn	X	X		
RPM	Revolutions Per Minute			X	
RTN	Route Name	X	X	X	X
SBS	Switch Bank Status			X	
SOG	Speed Over Ground	X	X	X	X
SYT	System Time	X		X	
TCT	Target Count		X	X	X
TMP	Water Temperature		X	X	
TMR	Time Remaining	X	X	X	X
TOA	Time Of Arrival	X	X	X	
TPO	Air Temperature			X	
TRG	Transmission Gear			X	
TRT	Transmission Temperature and Pressure			X	
TTG	Time To Go	X	X	X	
TWA	True Wind Angle		X	X	X
TWD	True Wind Direction		X		
TWS	True Wind Speed		X	X	X
TXT	Text		X		
UTC	Universal Time Coordinate	X	X	X	
VAR	Magnetic Variation	X	X	X	
VMG	Velocity Made Good	X	X	X	
VPE	Vertical Position Accuracy	X	X	X	
WPN	Waypoint Name	X	X	X	
XTE	Cross Track Error	X	X	X	X



Instruments: TCP/IP NMEA Client

Select TCP/IP at the top left corner of the Instruments View

To set up "**TCP/IP NMEA Client**" which uses the device WiFi, enter the host IP address (i.e. 10.0.1.2 or somehost.com) and the host port (i.e. 2114) of the NMEA data server (i.e. MacENC or Coastal Explorer or GPSTGate or AviaSail)

Most often a "**TCP**" connection is used, however "**UDP**" is offered. Enable "**Link**" to make the connection to the NMEA data server. Select the "**Save**" button to exit. Position, Speed and Course can come from either NMEA GPS or AIS transponder. In the event the TCP/IP connection is lost, Locations Services will be reverted to. The "**Bookmarks**" button can be used to recall previous hosts and ports used



Enable Waypoints – offers an audio and visual alert if the TCP/IP connection is lost



Location Services – use the device Location Service for position, speed, course, etc. otherwise process all other NMEA data




Disconnect Alarm – offer an audio and visual alert if the TCP/IP connection is lost



AP Repeat – When a waypoint is active, the NMEA data sentences \$GPAPB, \$GPBOD, \$GPBWC, \$GPGGA, \$GPRMB, \$GPRMC, \$GPXTE, \$GPVTG will be sent to the TCP/IP host. "**True/Mag**" selection will set whether bearings sent in the \$GPAPB NMEA sentence to the Autopilot are True or Magnetic. Note: iPad only




Email – will send waypoints using NMEA data sentence \$GPWPL to the TCP/IP host. Note: iPad only



Instruments: TCP/IP NMEA Client





NMEA 0183 Sentences Supported		NMEA 2000 PGNS Supported
\$__BOD,	\$__RMC,	126992,
\$__BWC,	\$__ROT,	127250,
\$__DBT,	\$__RTE,	127488,
\$__DPT,	\$__TXT,	127489,
\$__GGA,	!__VDM,	127493,
\$__GLL,	!__VDO,	127501,
\$__GSA,	\$__VDR,	127505,
\$__GSV,	\$__VHW,	127508,
\$__HDG,	\$__VTG,	128259,
\$__HDM,	\$__VWR,	128267,
\$__HDT,	\$__VWT,	129025,
\$__MWD,	\$__VXS,	129026,
\$__MTW,	\$__WPL,	129029,
\$__MWV,	\$__XTE,	129038,
\$__RMB,	\$__ZDA	129039,
		129284,
		129539,
		129540,
		129794,
		129809,
		129810,
		130306,
		130311



Create a Waypoint

A Waypoint is a position on a Chart that you want to make note of. Besides for marking positions, waypoints can be used to navigate to their position

There are 3 ways to create a Waypoint

-  **Single Tap** – Tap the desired location on the Chart and select Waypoint
-  **Long Touch** – holding down on the chart for two seconds, note: Long Tap New Waypoint needs to be enabled in Chart Settings
-  **Waypoints Screen** – select “+” in the top right corner of the Waypoints screen
 -  This also provides the option to select Port Search to find a marine, NavAid or other object




Managing Waypoints

Select the “+” button to create a new Waypoint or select an existing Waypoint to view and/or edit





Select “Import/Export” to transfer Waypoints or routes to/from iNavX


Waypoints can also be imported by holding down a GPX, KML or KMZ file attachment in an email and selecting “Open in ... iNavX”

Slide across an individual Waypoint to delete it, or “Remove All Waypoints” to delete all




Waypoint can be customized by changing the Name, adding a Description and even assigning a Photo to the Waypoint

-  **Position** – shown by Lat/Lon, can also be changed
-  **Lock** – will prevent a Waypoint from being changed
-  **Show** – will determine if a Waypoint is plotted on the chart
-  **Goto** – can be selected to navigate to the Waypoint




Editing Waypoints

A Waypoint can be moved on the Chart by single-tapping its name, then dragging its location





Tapping a Waypoint name a second time will display a menu



Navigating to a Waypoint





When a Waypoint is being navigated to, it's bearing distance, time to go, and cross track error will be displayed in the Instruments view and blue line from the current position to the Waypoint will be plotted on the Chart

-  **Navigate to Waypoint** – Double-tap the Waypoint on the Chart View of select the desired Waypoint from the Waypoints Screen and select “Goto”
-  **Cancel Waypoint Navigation** – Repeat the Navigate to Waypoint process and select “Cancel Goto”



Creating a Route

A Route is a collection of one or more connected Waypoints


-  **Routes** are accessed via the Waypoints view menu on the iPhone and the Routes view on the iPad
-  Use the “+” button in the top right corner to create a new Route
-  Use the “**Select Waypoint**” or the “+” button on the left side of the Route screen to add Waypoints to the Route
-  Waypoints can also be added to a selected Route by tapping a waypoint name twice on the Chart view and selecting “**Add to Route**”





Editing a Route

To edit the route, select it from the route list

- Use the “+” button to add more waypoints
- The “**Distance**” button will toggle between segments and cumulative route distance


Use the  Action button in the top right to access the Route menu


- Edit - to remove or reorder waypoints using the move icon to the right of the Waypoint name
- The  Action button will also allow a route to be inverted, duplicated, printed or opened in apps that support KML routes (i.e. Google Earth)




Navigating a Route


Selecting the “**Goto**” button in the Route View will begin navigation to the first Waypoint in the route

 Automatic advancement to the next waypoint in the route will occur if the current position is inside the arrival distance of a waypoint OR the current position crosses the line perpendicular to the waypoint origin line which passes through the waypoint

 If the waypoint arrival distance is set to None, then no automatic advancement to the next waypoint will occur

 Subsequent waypoints in the route can be navigated to by selecting “Next” in the Route view

 When a waypoint in a route is being navigated to, it's bearing, distance, time to go, and cross track error will be displayed in the Instruments view and a blue line from the current position to the waypoint will be plotted on the chart. In addition the distance, time to go to the last waypoint in the route and route name will be shown in the instruments view in the DTR:, TMR:, TOA: and RTN: fields.





 Selecting those fields will display an extended view with all waypoints in the active route. The selected route will be plotted on the chart. The “**Cancel Goto**” button on the Waypoints view can be selected to end navigation to a waypoint








Tracking


Track is a log or recorded history of up to the last 500 NM travelled

Select **Record** to enable track logging

-  Off – no track logging
-  Hi – Record up to 100 NM at the highest resolution
-  Med – Record up to 500 NM at medium resolution
-  Low – Record up to 1,000 NM at the lowest resolution









Enable "**Background Recording**" in order to have track records recorded even when **iNavX** is suspended. Note: This can drain the battery and only works with Location Services


-  Select "**Track Back**" to create and navigate to a "**Track Back**" waypoint which dynamically traverses the inverted track history. Initially the navigation will be to the closest track segment within 50 NM
 -  Tapping "**Track Back**" a second time or selecting "**Cancel Goto**" on the Waypoints view will cancel the "Track Back"
-  Select "**Remove**" to delete the track history. The track will be plotted on the chart as line segments between each track point that is less than 5nm apart
-  Select "**Export**" to transfer track from iNavX to iNavX Account, Email or "**Share on Facebook**"
-  Tracks can also be imported by holding down a GPX, KML or KMZ file attachment in an email and selecting "**Open In... iNavX**"






Anchor Alarm


The Anchor Alarm can be found under the "More" Tab > Anchor Alarm

-  The "**Anchor Alarm**" will trigger (audible and visual alert when enabled) if the position changes more than the selected NM distance
-  In order for the Anchor Alarm to work, iNavX must be active (i.e. running) and have a good position fix (as indicated by "HPE:" in the Instruments view)
-  The Anchor Alarm perimeter is plotted on the chart
-  "**AAD:**" in the Instruments view will display the amount of drift
-  Use the "**Anchor**" button to set the approximate location of the anchor relative to your position. Make sure the Anchor Alarm perimeter distance is greater than the distance to the anchor, otherwise the alarm will trigger immediately after enabling
-  The "**Scope**" button can be used to get a recommended amount of anchor rope to deploy
-  "**Test**" can be selected to simulate the alarm
-  Anchor Alarm audio will repeat until "**Cancel**" button is selected or the Alarm view is dismissed with "**Save**" button. To make sure the audio alert can be heard, confirm the "**Mute**" button is not turned on AND The Volume slider in the device "**Settings**" "**General**" "**Sounds**" "**Ringer and Alerts**" is at maximum level. "**Change with Buttons**" can be enabled to allow the buttons on the side of the device to control the volume level



Forecast


-  **"Tides"** will open the [AyeTides](#) app (if installed) to the center of the Chart view position. **iNavX** can be returned to from the **AyeTides** main menu by pressing the **"Back to iNavX"** button in the upper left hand corner
-  **"Theyr Weather Settings"** allows weather forecasts to be plotted over the Chart view. This feature does require a Theyr Weather subscription and an internet connection
-  **GRIB** is a weather forecast



Theyr Weather

After activating the Theyr Weather subscription, select the region and forecast required


- Wind / Wave / Pressure / Precipitation
- Air Temperature
- Precipitation
- Pressure
- Sea Surface Temperature
- Wave Height
- Wind Speed
- Wind / Pressure
- NEXRAD Precipitation
- Tidal Stream
- Note: certain parameters are available as regional forecasts only



Once a forecast is selected the [<] and [>] buttons will decrement or increment the forecast date

The Animate button on the right can be selected to have the forecasts cycled

Tapping on Settings on the left will bring up the Forecast selection screen



GRIB

A GRIB is a weather forecast



Use the "**Request GRIB**" to have the GRIB sent to your device



"**Email**" will make use the Mail app to make the request. The GRIB forecast will come in as an email with a file attachment in the Mail app. To import hold down the GRB file attachment in the email and select "**Open In...**" "**iNavX**"



Alternatively, the "Import GRIB" button will show available GRIBS



After requesting a GRIB, it will take approximately one minute before the GRIB is available




Once a GRIB is selected in the "**GRIBs**" section, the [**<**] and [**>**] buttons on the chart view will decrement or increment the forecast date



The Animate button can be selected to have the forecasts cycled



Note: GRIB data is typically at 0.5 degree resolution so be sure to use a chart that covers enough area to see the GRIB data (i.e. small scale)



Quick FAQs

Where do you get iNavX?

[iNavX in the iTunes App Store.](#)

Is there a charge for the high resolution NOAA US waters marine charts?

No, iNavX comes with free access to the high resolution NOAA US waters marine charts

Is there a charge for the marine charts and data?

Yes. iNavX provides access to the largest chart and data library. All additional charts are available for purchase through the iNavX In-App Chart Store.

What areas do the marine charts and maps include?

In addition to the NOAA US waters marine charts, iNavX provides access to the largest chart and data library. Visit the iNavX In-App Chart Store for more details.

Are the marine charts and maps the latest editions?

Yes, since they download directly from an official chart server. They can be updated at any time during the subscription period.

Where can I learn more information about the NOAA US waters marine charts?

[Here](#) – to see a list of NOAA Chart symbols and other information, use the search results from any Internet search engine with the phrase "NOAA chart No. 1"

Are the marine charts and maps stored locally on my device?

Yes. This means once they are downloaded an internet connection is not needed to use the charts or maps.

How much storage space do the marine charts and maps take?

Depends on how many charts and maps have been downloaded. Individual charts and maps can be deleted. Typical chart or map takes under 1 MB of storage.

Does iNavX need a cell or Wi-Fi internet connection to use the marine charts or maps?

No. An internet connection is only needed to download selected charts and maps. Once charts and maps are downloaded they can be used at any time regardless of internet connectivity. Note: regular raster and vector charts download once and stay in memory with no further need of an Internet connection. Charts in memory do not expire but chart updates do cease once a subscription ends, and if device memory is reset or the device is replaced, iNavX requires a chart subscription renewal.

What devices is iNavX compatible with?

iPad, iPad mini, iPod touch, and iPhone. iNavX supports any iOS device running iOS10 or higher

Does iNavX support the device compass?

Yes. The compass will be used to orient the position icon on the chart including course up, the compass banner and the "HDG:" in the Instruments view. Course over ground can also be used.



Quick FAQs

I have more than one device, can iNavX be installed on all devices?

Yes. iNavX is a universal app and will be made available to all devices with the same iTunes Account. Alternatively, when you sync any device with your PC or Mac, all apps purchased from the iTunes app store will be installed. This means you purchase an app once and install on all your devices.

Does iNavX support external GPS receivers for devices without a built in GPS?

Yes. We support the Bad Elf GPS, the Dual XGPS150 Universal Bluetooth GPS / Dual XGPS170 Universal Bluetooth GPS, the Garmin GLO, and the Magellan ToughCase

Does iNavX track my location?

Yes, utilizing your devices in-built GPS, iNavX will actively track your location. This functionality also works without cell service.

What Location priority order does iNavX use?

When "Location Services" is enabled in the iNavX TCP/IP NMEA Client this means Location Services will be used for position, speed, and course. This setting is typically enabled when GPS NMEA data is not available over TCP/IP connection, but other NMEA data such as depth or wind is.

What version of the iOS does iNavX require?

iOS 10 or later. iNavX no longer support iOS 5 since Apple's developer tools dropped support for it some time ago. You should however be able to download an earlier version of iNavX that does support your device which you can read more about [here](#).

Does iNavX work in places where there is not marine chart or map coverage?

Yes. There is a basic low scale world chart included and the instrument and waypoints functionality is not dependent on available or loaded charts.

Does iNavX work with the NOAA ENC vector charts?

No. The NOAA ENC vector chart coverage is incomplete and the NOAA ENC vector charts do not have the look of traditional paper charts.

I have charts on my PC or Mac, can I use those with iNavX?

No. the chart providers have strict license and usage terms that restrict cross device usage. Only charts purchased on iNavX can be used on iNavX.

What is the current version of iNavX?

v5.5.2

How much are iNavX updates?

No additional charge and all iNavX updates will arrive via the Apple iPhone app store. On the device, Select "App Store", then select "Updates".

How does iNavX compare with the MacENC or GPSNavX feature set?

[Comparison Table](#)

Does iNavX have analog graphics for instrument data?

Yes, tap on any instrument value and an analog graphic is available (speed, course, wind, satellites, route, depth).

Does iNavX support AIS receivers and transponders?

Yes via TCP/IP. Targets are plotted on the chart with real-world scaling. An AIS Transponder can be used to provide own position, speed and course to iNavX. SART and NavAids are supported.



Quick FAQs

Does iNavX support NMEA data?

Recommended multiplexers:

- [Brookhouse iMux WiFi multiplexer](#)
- [Brookhouse eMux WiFi multiplexer](#)
- [Comar NMEA-2-WiFi multiplexer](#)
- [DigitalYacht iAIS WiFi receiver & multiplexer](#)
- [DigitalYacht WLN10 WiFi multiplexer](#)
- [ShipModul Miniplex-2 WiFi multiplexer](#)
- [Redpark GPS Cable](#)
- [vYacht NMEA Wifi router](#)
- [DMK Yacht Instruments Box](#)
- [Vesper Marine XB-8000 / WatchMate Vision](#)
- NMEA 2000 support: [Chetco Digital Instruments SeaSmart WiFi](#) OR
Combine an [Actisense NGW-1 ISO](#) with one of the above multiplexers

I don't have an AIS receiver or transponder, is there another way to get AIS data into iNavX?

Yes, in selected locals the SiiTech AIS server can be used. The SiiTech AIS server provides AIS targets within 30 NM of device position or any selected waypoint.

I have waypoints, routes, or tracks, how do I transfer those to/from iNavX?

iNavX can import and export waypoints, routes and tracks via email and from your iNavX account. This includes sending to MotionX and Google Earth apps. iNavX can import and export waypoints, routes and tracks via iTunes

Can I upload my track to Google Earth?

iNavX can export the track or via email

Does iNavX support GRIB weather forecasts?

iNavX can import and display GRIBs

Is there a Full Screen mode in iNavX?

Yes, with the tap of the screen the chart can be expanded to fill the entire view

Do charts in iNavX get backed up via USB synchronization or iCloud?

NOAA Charts backup to iCloud if iCloud backup is enabled on the users device, but no chart files are archived to a computer hard drive



Quick FAQs

What measurement units does iNavX support?

Nautical miles, statute miles, kilometers, yards, and meters, true and magnetic bearings, degrees and fractional minutes and degrees minutes and seconds. All distance and bearing measurements are computed using Great Circle routing.

Is there a user's guide for iNavX?

Yes here: [Guide](#)

Is there a tutorial for iNavX?

Yes here: [Tutorial](#)

Is there a user's forum for iNavX?

Yes here: [Forum](#)

Is there a trial or demo version of iNavX?

No. Apple's official policy is not to allow trial or demo versions of apps.

Does iNavX include any AdWare?

No. It is our policy not to include any advertisements in our software.

What languages is iNavX localized in?

English, Dutch, French, German, Italian, Spanish, Swedish.

Does iNavX support ActiveCaptain?

Not at this time, it is something we are considering for the future.

Is iNavX available on Android?

iNavX is only available for iOS devices. We have not had the resources to build an Android version, it is something we hope to do at some point in the future.

Support for Mr. Tides

Mr. Tides is produced by another company, they can be reached for all questions and support items here –

<http://mrtides.com/support.php>



Using iNavX with Brookhouse iMux

Go to the device home screen

Select "Settings" > "Wi-Fi" > Set "Wi-Fi" to "ON" > Select "Brookhouse_iMux".

If prompted for a password, enter BrookhouseXX (where XX is the serial number of the iMux)

Launch iNavX

- Select "**TCP/IP NMEA Client**" on the iNavX Preferences menu
- Enter the Host "**169.254.1.1**" (Note: MK3 models use "**192.168.1.99**")
- Enter Port "**2000**" (Note: MK3 models use "**10110**")
- Select "**TCP**"
- Set "**Enable Waypoints**" to "**ON**" to import and and navigate to active waypoint or route of the connected GPS receiver
- Set "**Location Services**" to "**ON**" If there is no GPS receiver connected to the iMux.
- Set "**AP Repeat**" to "**ON**" in order to have NMEA data for the active waypoint sent to the iMux NMEA differential (RS422) out while iNavX is running. When "**OFF**" or iNavX is not running, the NMEA data from iMux NMEA input CH1 will be sent to iMux NMEA differential (RS422) out.
- Enable "**Link**"
- Select "**Save**" button

Notes:

- Connecting iMux to NMEA data. Optional connections:
- Connect GPS receiver to iMux NMEA input CH1.
- Connect DSC output from VHF radio to iMux NMEA input CH2. When a DSC distress message comes in, iNavX will create a waypoint at the reported position. In order for this to work be sure "Enable Waypoints" on the TCP/IP NMEA Client setup.
- Connect other NMEA compatible instruments to iMux NMEA input CH3.
- Connect AIS receiver or transponder to iMux NMEA input CH4.
- Connect PC or Mac to iMux RS232.
- Connect AP to iMux NMEA Differential (RS422) Out.



Using iNavX with Chetco Digital Instruments SeaSmart WiFi

Go to the device home screen

Select "Settings" > "Wi-Fi" > Set "Wi-Fi" to "ON" > Select "SeaSmart Adhoc Network"

Find the free **Fing** app in the Apple iTunes app store and install on device

Launch Fing on device, Fing will discover the SeaSmart AdHoc Network including the Host address of the SeaSmart WiFi which will be labeled "PRONET"

Launch iNavX

- Select "**TCP/IP NMEA Client**" on the iNavX "**Preferences**" menu
- Enter the Host as shown above in Fing app "PRONET"
- Enter Port "**10001**"
- Select "**TCP**"
- Set "**Enable Waypoints**" to "**ON**" to import and navigate to active waypoint or route of the connected GPS receiver
- Set "**Location Services**" to "**ON**" If there is no GPS receiver connected to the SeaSmart WiFi.
- Enable "**Link**" and select "**Save**"

Notes:

The SeaSmart WiFi will assign a different Host address each time powered up. In order to have a fixed Host address: Enter the Host address as previously found by Fing into Safari URL to bring up the SeaSmart WiFi web page

Select "**Adapter Setup**"

Select "**Network Setup**"

Select "**Network 2**"

Select "**Configuration**"

Set "**State:**" to "**Enabled**"

Set "**BOOTP Client:**" to "**OFF**"

Set "**DHCP Client:**" to "**OFF**"

Enter the desired Host address into the "**IP Address:**" field. Recommend 169.254.XXX.XXX (i.e. 169.254.109.106)

Select "**Submit**"

Select "**System**"

Select "**Reboot**"



Using iNavX with Coastal Explorer

If your PC and iPhone or iPad or iPod Touch are connected to a WiFi or ad-hoc network you can link to the Coastal Explorer NMEA data.

Launch the latest version of **Coastal Explorer**

Select "**Tools > Configure Vessel and Electronics...**"

Select "**Data Ports**"

Select "**Data Server...**"

Check "**Enable Data Server**"

Go to the device home screen

Select "**Settings**" > "**Wi-Fi**" > Set "**Wi-Fi**" to "ON"

Be sure to select the network that your PC running Coastal Explorer is connected to.

Launch iNavX

Select "**TCP/IP NMEA Client**" on the iNavX "**Preferences**" menu

Enter the Host, which is the IP address displayed in Coastal Explorer "**Data Server**" "**IP Address:**"

Enter the Port, which is the value displayed in the Coastal Explorer "**Data Server**" "**TCP Port:**"

Select "**TCP**"

Enable "**Link**"

Select "**Instruments**" on the iNavX menu to see the NMEA data being received via TCP/IP from Coastal Explorer



Using iNavX with Comar NMEA-2-WiFi

Go to the device home screen

Select "**Settings**" app > Select "**Wi-Fi**" > Set "**Wi-Fi**" to "**ON**" > Select "**NMEA-2-WIFI XXX**".

Launch iNavX

Select "**TCP/IP NMEA Client**" on the iNavX Preferences menu

Enter the Host "**169.254.1.1**"

Enter Port "**2000**"

Select "**TCP**"

Set "**Enable Waypoints**" to "**ON**" to import and and navigate to active waypoint or route of the connected GPS receiver

Set "**Location Services**" to "**ON**" If there is no GPS receiver connected to the NMEA-2-WiFi.

Enable "**Link**"

Select "**Save**" button

Notes:

Connecting NMEA-2-WiFi to NMEA data:

Connect GPS receiver to NMEA-2-WiFi NMEA input 4,800

Connect AIS receiver or transponder to NMEA-2-WiFi NMEA input 38,400.



Using iNavX with DigitalYacht iAIS or WLN10 or NavLink

Go to the device home screen

Select "**Settings**" app > Select "**Wi-Fi**" > Set "**Wi-Fi**" to "**ON**" > Select "**DY-iAIS-XXXX**" or "**DY-WLN10-XXXX**"

Launch iNavX

Select "**TCP/IP NMEA Client**" on the iNavX "**Preferences**" menu

Enter the Host "**169.254.1.1**"

Enter Port "**2000**"

Select "**TCP**" (Note: If iAIS or WLN10 configured for UDP, then select "**UDP**")

Set "**Enable Waypoints**" to "**ON**" to import and and navigate to active waypoint or route of the connected GPS receiver

Set "**Location Services**" to "**ON**" If there is no GPS receiver connected to the iAIS or WLN10. This will allow iNavX to use the device "**Location Services**"

Set "**AP Repeat**" to "**ON**" in order to have NMEA data for the active waypoint sent to the WLN10 NMEA out while iNavX is running.

Enable "**Link**"

Select "**Save**" button



Using iNavX with MacENC

If your Mac and iPhone or iPad or iPod Touch are connected to a WiFi or [ad-hoc network](#) you can link to the MacENC NMEA data.

Go to the device home screen

Select "**Settings**" > Select "**Wi-Fi**" > Set "**Wi-Fi**" to "**ON**" > Be sure to select the network that your Mac running MacENC is connected to.

Launch iNavX

Select "**TCP/IP**" on the MacENC "**GPS**" menu

Select "**Enable**" for the Server

Select "**GPS**", "**Instruments**", "**AIS/RADAR**"

Unselect "**Processed**"

Notes:

Make sure your network is established before starting MacENC so the correct Host IP address is displayed in the MacENC TCP/IP NMEA window. In some cases the Host IP address displayed in MacENC may not be correct or unavailable, so open System Preferences and select "**Network**" to find the correct Host IP address. Make sure the OS X Firewall in System Preferences "**Security and Privacy**" is not blocking any connections to MacENC. Typically for an AdHoc network the Firewall can be disabled.

Select "**TCP/IP NMEA Client**" on the iNavX "**Preferences**" menu

Enter the host as shown in the MacENC "**TCP/IP NMEA Data**" window Server "**Host**"

Enter the port as shown in the MacENC "**TCP/IP NMEA Data**" window Server "**Port**"

Select "**TCP**"

Enable "**Link**"

Enable "**Enable Waypoints**"

Select "**Save**" button

Select "**Instruments**" on the iNavX menu to see the NMEA data being received via TCP/IP from MacENC



Using iNavX with Mølgaard Marine SeaMate1A

Go to the device home screen

Select "**Settings**" app

Select "**Wi-Fi**"

Set "**Wi-Fi**" to "**ON**"

Select "**SEAMateXXXX**". If another network is selected, first select the blue disclosure button next to the selected network and then select "**Forget this network**"

Select the blue disclosure button next to the "**SEAMateXXXX**"

Set "**IP Address**" as "**Static**"

Set "**IP Address**" as "**192.168.127.200**"

Select "**Wi-Fi**" back button

Exit "**Settings**" and launch iNavX

Select "**TCP/IP NMEA Client**" on the iNavX Preferences menu

Enter the Host "**192.168.127.129**"

Enter Port "**10002**" for using the SeaMate1A CH2 NMEA data OR "**10001**" for using the SeaMate1A CH1 AIS NMEA data

Select "**TCP**"

Set "**Enable Waypoints**" to "**ON**" to import and and navigate to active waypoint or route of the connected GPS receiver

Set "**Location Services**" to "**ON**" If using SeaMate1A CH1 AIS NMEA data

Set "**AP Repeat**" to "**OFF**"

Enable "**Link**"

Select "**Save**" button



Using iNavX with PolarCOM

Launch PolarCOM on your PC

[control] or right click on the PolarCOM icon in the dock or tray

Select "**Configure**" from the menu

Assuming you already have the PolarCOM ports setup for the NMEA input into your PC:

Select "**Add**" button in the PolarCOM Configuration window

Enter "**TCP**" for "**Visible Name**"

Select "**Network Server**" for the type

Enter "**0.0.0.0**" for "**address**"

Enter "**2114**" for the "**port**"

Select "**Mux Out**" for the "**Direction**"

Select "**TCP**" for the "**Protocol**"

Select the "**Add**" button

Go to the device home screen

Select "**Settings**" app

Select "**Wi-Fi**"

Set "**Wi-Fi**" to "ON"

Be sure to select the network that your PC running PolarCOM is connected to. If another network is selected first select the blue disclosure button next to the selected network and then select "**Forget this network**"

Exit "**Settings**" and launch iNavX

Launch iNavX

Select "**TCP/IP NMEA Client**" on the iNavX Preferences menu

Enter the Host (This is the IP address of your PC running PolarCOM)

Enter Port "**2114**"

Select "**TCP**"

Set "**Enable Waypoints**" to "**ON**" to import and and navigate to active waypoint or route of the GPS receiver connected to PolarCOM

Set "**Location Services**" to "**ON**" If there is no GPS receiver connected to your PC

Enable "**Link**"

Select "**Save**" button



Using iNavX with SailTimer Wind Vane

Go to the device home screen

Select "**Settings**" app

Select "**Wi-Fi**"

Set "**Wi-Fi**" to "**ON**"

Select "**SailTimerWindVane.com**". If another network is selected, first select the blue disclosure button next to the selected network and then select "**Forget this network**"

Exit "**Settings**"

Launch iNavX

Select "**TCP/IP NMEA Client**" on the iNavX Preferences menu

Select mode to "**UDP**"

Enter Port "**55554**"

Set "**Location Services**" to "**ON**"

Enable "**Link**"

Select "**Save**" button



Using iNavX with ShipModul MiniPlex-2Wi

Go to the device home screen

Select "**Settings**" app

Select "**Wi-Fi**"

Set "**Wi-Fi**" to "**ON**"

Select "**MiniPlex-2Wi:xx:xx**". If another network is selected, first select the blue disclosure button next to the selected network and then select "**Forget this network**"

Exit "**Settings**"

Launch iNavX

Select "**TCP/IP NMEA Client**" on the iNavX Preferences menu

Enter the Host "**169.254.1.1**" (Note: versions 3.17 and later use "**10.0.0.1**")

Enter Port "**10110**"

Select "**TCP**"

Set "**Enable Waypoints**" to "**ON**" to import and and navigate to active waypoint or route of the connected GPS receiver

Set "**Location Services**" to "**ON**" If there is no GPS receiver connected to the MiniPlex-2Wi

Set "**AP Repeat**" to "**ON**" in order to have NMEA data for the active waypoint sent to the MiniPlex-2Wi Out1

Enable "**Link**"

Select "**Save**" button



Using iNavX with SiiTech AIS NMEA Data Server

The SiiTech AIS server will provide AIS NMEA data in certain locales. [Coverage areas](#). The radius of the AIS NMEA data provided is 30NM from your device position or a selected waypoint. Note: Your device must have a WiFi or cell connection in order to connect to the SiiTech AIS Server. The SiiTech AIS Server will disconnect if there is no coverage for the selected position. Suspending iNavX either with the home or lock button disconnects from the SiiTech AIS server. Upon resuming iNavX a re-connect will be made, however this will fail if the re-connect is made within one minute of suspending iNavX.

Launch iNavX

Select "TCP/IP NMEA Client" on the iNavX "Preferences" menu

Select the "Account" button and enter SiiTech Account:

Email: test@inavx.com

Password: data

Position: Can either be the device "Position" or a waypoint for the AIS NMEA data origin


Select "Save" button

Using the bookmarks button select "inavx.web-ais.net 9991

"Set "Location Services" to "ON"

Enable "Link"

Select "Save" button



Using iNavX with Vesper Marine XB-8000 / WatchMate Vision

Go to the device home screen

Select "**Settings**" app

Select "**Wi-Fi**"

Set "**Wi-Fi**" to "**ON**"

Select "**VesperXB**". If another network is selected, first select the blue disclosure button next to the selected network and then select "**Forget this network**"

Find the password in the Installation Guide included with the Vesper Marine unit

Exit "**Settings**"

Launch iNavX

Select "**TCP/IP NMEA Client**" on the iNavX "**Preferences**" menu

Enter the Host "**192.168.15.1**"

Enter Port "**39150**"

Select "**TCP**"

Set "**Location Services**" to "**OFF**"

Enable "**Link**"

Select "**Save**" button



Using iNavX with vYacht NMEA

Go to the device home screen

Select "**Settings**" app

Select "**Wi-Fi**"

Set "**Wi-Fi**" to "**ON**"

Select "**vYachtWifi**". If another network is selected, first select the blue disclosure button next to the selected network and then select "**Forget this network**"

Exit "**Settings**"

Launch iNavX

Select "**TCP/IP NMEA Client**" on the iNavX Preferences menu

Enter the Host "**192.168.1.1**"

Enter Port "**2947**"

Select "**TCP**"

Set "**Location Services**" to "**ON**" If there is no GPS receiver connected to the vYacht NMEA

Enable "**Link**"

Select "**Save**" button





iNavX

#1 Marine Navigation App

Website

<http://inavx.com>



Need more info? Contact us:
support@inavx.com



iNavX

50